

**WARNING READ INSTRUCTIONS CAREFULLY BEFORE USE**

## The Cube 2.4m<sup>2</sup> - 3m<sup>2</sup> - 4m<sup>2</sup>

### SETUP - INFLATION

Recommended procedure below. For safety reasons it is recommended that 2 persons set up any marquee.  
Ensure area is free from any sharp objects & overhead objects.



ONE

Layout ground sheet out and roll out the marquee.



TWO

Connect pump to inlet valve using the (OUT) end of pump.



THREE

Turn pump on and proceed to inflate.



FOUR

Ensure all legs are lined up. Check frame is firm (do not overinflate).



FIVE

Check pressure on gauge, gauge should read approx 1psi. Remove pump.



SIX

As soon as pressure is correct proceed to attach sandbags or pins to legs.



SEVEN

Attached the velcro walls.



EIGHT

Continue to to attach velco walls.



VIEW OF CUBE FULLY INFLATED & WALLS ATTACHED



# BACK DOWN - DEFLATION

Recommended procedure below. For safety reasons it is recommended that 2 persons set up any marquee.  
Ensure area is free from any sharp objects & overhead objects.

ONE



Lay ground sheet out into position to protect inflatable.

TWO



Connect pump to inlet valve using the (IN) end of pump. Turn pump on and proceed to deflate.

THREE



Remove all sandbags and pins and store.

FOUR



Deflate and allow cube to fold down.

FIVE



Proceed to roll marquee up.  
Pack marquee into protective cover.

SIX



Roll up ground sheet and store inflatable and all accessories into bag.

## ACCESSORIES

INCLUDED



Pins

INCLUDED



Sandbags

INCLUDED



Pump

INCLUDED



Repair Kit

INCLUDED



Gauge

NOT INCLUDED



Generator

NOT INCLUDED



Extension Lead

NOT INCLUDED



Hammer

NOT INCLUDED



Ground Sheet